


引脚	棕	X1	引脚
1	橙	X2	18
2	黄	X3	19
3	绿	X4	20
4	蓝	Y1	21
5	紫	Y2	22
6	灰	Y3	23
7	白	Y4	24
8			25
9			-
10	红	+24V	-
11	黑	COM	26
12			27



引脚	X1	黄1
18	X2	黄2
19	X3	黄3
20	X4	黄4
21	Y1	黄5
22	Y2	黄6
23	Y3	黄7
24	Y4	黄8
25		
-		
-		
26	+24V	黄9
27	COM	黄10

电柜侧